




XM-06



XM-12





XM-25



1 : Maximum differential - Ecart maximum - Maximale hysteresen - Intervalos máximos - Differenziali max - intervalos maximos
2 : Minimum differential - Ecart minimum - Minimale hysteresen - Intervalos mínimos - Differenziali min - intervalos minimos


XX/XMA

XMP




PH : High setting point - Point haut - Oberer Schalterpunkt - Punto de disparo superior - Punto di scatto superiore - Ponto alto
PB : Low setting point - Point bas - Unterer Schalterpunkt - Punto de disparo inferior - Punto di scatto inferiore - Ponto baixo

Setting
Réglage
Einsellungen
Adjustes
Regolazione
Reglagem



Fixing bracket
Equerre de fixation
Befestigungswinkel
Escuadra de fijación
Squadra de fissaggio
Esquadro de fixação

XMA-ZL001



DANGER / PELIGRO / DANGER

HAZARDOUS VOLTAGE

Disconnect all power before servicing equipment.

Electric shock will result in death or serious injury.

TENSION PELIGROSA

Desenergice el equipo antes de realizarle servicio.

Una descarga eléctrica podrá causar la muerte o lesiones serias.

TENSION DANGEREUSE

Couper l'alimentation avant de travailler sur cet appareil.

Une électrocution entrainera la mort ou des blessures graves.

FOR XMA / XMX ONLY

SCALE MUST BE READ WHEN THE PRODUCT IS NOT TRIPPED

SEULEMENT POUR XMA / XMX

LECTURE DE L'ECHELLE A EFFECTUER AVEC PRODUIT NON ENCLENCHE

SOLO PER XMA / XMX

LETTURA ETICHETTA DA EFFETTUARE CON PRODOTTO A RIPOSO

**EXAMPLE
ESEMPIO**




PRECISION: ±10%
PRECISION: ±10%
PRECISION: ±10%




Pressure switches
 Pressostats
 Druckwaechter
 Presostatos
 Pressostati
 Pressostatos


XMX



XMA





XMP





Dimensions - Encombrements - Abmessungen - Dimensiones - Dimensioni - Atravancamentos



XMX/XMP-A06●21●●/A12●21●●





XMX/XMP-A06●24●●/A12●24●●





XMX/XMP-A25●21●●





XMA-●06●21●●/XMA-●12●21●●



XMA-●06●24●●/XMA-●12●24●●




XMA-●25●21●●




XMP-B/C●●●●●●●●




XMP-D/E06/12●●●●●●



XMP-R06/12●●●●●●



XMP-R25●●●●●●



XMX/XMAXMP

